




ROUTER SET-UP INSTRUCTIONS

- 1) Locate the label with your **SSID (Wi-Fi Network Name)** and **Password** on the bottom of the device.



- 3) Connect the supplied USB-C power adapter to the power port on the device, then plug it into a nearby AC outlet.



- 2) Connect the supplied Ethernet cable from the WAN port on your MH7601 device to your ethernet jack in your living room.



- 4) The front light will blink white while the device powers on and then blink blue while attempting to connect to the internet. The light will illuminate solid white once the connection to the internet is successful.



Please note that you may need to “Forget” (Disconnect your devices from) your prior Wi-Fi network in order to connect to this new one.